

Exterior Repair-Kit Instructions

V 1.1.7-3-14

Material Provided

- Scratch and Brown Stucco (gray)
- Finish Stucco (white)
- Base Paint
- Finishing Glaze

Material / Tools not provided, but required

- Water
- Angle Brush
- Color Washing Brush
- SEAL-KRETE® Water Protective Sealer
- Mixing bowl

Mixing Instructions

Mix your Base Coat Stucco/Finish Stucco with water. Slowly pour the contents of the bag into the mixing water. Mix 3 to 5 minutes until a firm, workable consistency is achieved. If more water is needed, add small amounts at a time and continue to mix until desired consistency is achieved.

Process

- Base Stucco – Day One

Mix your “**Scratch and Brown Base Coat Stucco**” and begin spreading using putty knife.

When spreading the mud, spread around the edges first. Pull mud in an upward “r”-shaped motion. Be sure base coat fully covers the damaged area. Be sure scratch and brown coat matches the thickness of the old stucco. Let the surface dry at least 24 hours.

- Finish Stucco – Day Two

Use spray bottle to wet wall so second coat does not take off too quick (Otherwise it will be hard to smooth out and float).

Mix your “**Finish Coat Stucco**” and begin spreading using putty knife.

Be sure the thickness matches the thickness of old stucco. Depending on the texture you may have to knock down the texture, meaning rubbing lightly with your trowel flat. Let the surface dry at least 24 hours.

- SEAL-KRETE® Water Protective Sealer - Day Three

Apply a layer of SEAL-KRETE® Water Protective Sealer to the oven exterior wall using brush. Let the surface dry at least 2 hours.

- Color Coat - Day Three

Mix exterior color coat as needed. Spread a thin even coat to make it look like a sandy, but smooth surface. Rub out any noticeable lines or defects and make sure all edges are rubbed into the existing stucco.

Let the surface dry until you can touch it, and the color does not come off to the touch. But DO NOT let it get too dry. Usually about 10 to 20 minutes.

Apply your second color coat. Let the surface dry at least 12 hours.

- Tuscan Glaze Finish (Tuscan Glazing Technique) - Day Four

Step 1. Using a color washing brush, apply Tuscan Accents in small crisscross X patterns. Work in 3' x 3' sections using random strokes. Use a light touch and vary your strokes to create random X patterns.

Step 2. In the same 3' x 3' section, without reloading the brush and while the painted section is still wet, blend the X pattern brush strokes using long, sweeping motions going both vertically and horizontally. This ensures a blended, smooth appearance.